

WYSE - 30 V.D.U. SET UP PROCEDURE.

- 1) SHIFT Key + SET UP Key allows the config. screen to be accessed.
- 2) By using the $\leftarrow \uparrow \rightarrow$ selects the options.
- 3) HANDSHAKE = NONE. SCREEN: DARK CURSOR: BLOCK BLINK: ON
MODE: FDX
- 4) ▼ DATA BITS: 7 STOP BITS: 1 PARITY: ODD.
- 5) ▼ BAUD RATE: 9600 KEYS: UK
- 6) ▼ BLK/END: US/CR AUTO: NL ON CR: CR AUTOSCR: ON
LOCK: CAPS REPEAT: ON
- 7) ▼ CRT SAVER: ON PROTECT: NORMAL ATTRIBUTE: PAGE
- 8) ▼ COMPATIBLE MODE: ADDSVP ENHANCE: ON KEYPAD: NUMERIC
F KEYS: REMOTE TEST: OFF
- 9) TO SET UP THE F1 + F2 KEYS FOR PAGE UP/
PAGE DOWN. USE THE ▼ KEY TO SELECT
F1 PRESS CTRL B (COMES UP WITH $\$x$) TYPE IN 1.
▼ FOR F2 CTRL B (COMES UP WITH $\$x$) TYPE IN 2.
- 10) SHIFT + SET UP. SAVE CHANGES FOR POWER ON
Y = YES.
- 11) BACK TO NORMAL MENU.

2A.1.94.